
## look inside



nikpol

dwd xp drawer removal instructions

## How to correctly remove a DWD XP drawer.



STEP 1 Start with the drawer partially extended.



STEP 2 Apply gentle upward pressure as you begin to fully extend the drawer.



STEP **3** Maintain upward pressure as you reach full extension.





The drawer locking catch will release due to the upward pressure, not the pulling motion.



STEP **5** Remove the drawer from the slides. Always replace the drawer with the slides fully extended.

## nikpoľ

**Head Office (VIC)** 6-12 Fairchild Street Heatherton VIC 3202

**QLD** 35 Wentworth Place Banyo QLD 4014 **NSW** 2/5 Bessemer Street, Blacktown NSW 2148 Tel 1300 645 765 Web www.nikpol.com.au Email sales@nikpol.com.au